



# Hunt'n in Comfort

## Stump 1-Man Window Assembly Instructions

### Parts

- 4-Tinted Windows
- 8-Hinges
- 36-#6 Lock Nuts
- 32- #6-32 x 1/2" truss head bolts
- 4-Wing locks w/screws

- 1. Separate out your pieces of your window kit. Take one window and face it down on the drip edge.
- 2. Take one hinge and on the square side of the hinge line it up below the holes of the window edge. Take two of your truss head bolts, from the bottom up push it through the aligned holes of the window and the hinge. Tighten the bolt to a snug fit. Do not over tighten.
- 3. Repeat steps 1 and 2 on the second hinge for that same window.
- 4. After both hinges are bolted to the window, take your window and attach them to the Stump and match them up to the pre-drilled holes in the sidewall.
- 5. Insert a bolt and tighten to a snug fit. **Do not over tighten!** Limit to two bolts per hinge
- 6. After the window is completely attached to the stump and swings open properly, then you need to apply the "wing locks". These are easily assembled to the stump. They are put in the middle of the window opening opposite the side of the hinges of the window. Close the window and place the wing lock against the window and the stump. Determine where it would best be suited for easy twisting to allow the window to open and lock properly. Take the self-tapping screw and screw it into the stump. The tightness of the wing lock is determined on how tight you screw in the self-tapping screw. There is one wing nut for each corner of that side of the window.
- 7. Your window is finished!
- 8. Repeat Steps 1-5 to remaining windows.

**Any questions please give us a call at 800-262-4129 M-F 8-5!**

- Home

- **Tower Deer Stands**

- Stump Three Man

- Stump One Man

- Husky Hauler Trailer

- Husky Hauler Sled

- Attack Shack

- Sportsmans Countertop

- Food Plots and Minerals

- Pricing

- Dealer Locator

- Photo Gallery

- Testimonials

- Contact Us

- FAQ

**Call (800) 262-4129 or [click here](#) to email your order.**

31785 64th Avenue, Cannon Falls, Minnesota 55009

Copyright ©2007